



Gas & Electric Water Heater

Whale[®] Expanse™ WL8212, WL8202 Operating Instructions with iVan Control Panel





Со	Page n	
1.	Safety	1
2.	Warnings	2
3.	Specification	3
4.	Application	3
5.	Whale® Water Heater Operation Instructions	3
6.	Whale® iVan Control Panel Operation Instructions	5
7.	Whale [®] iVan Control Panel Troubleshooting	8
8.	Maintenance / Repairs	9
9.	EU Declaration of Conformity	10
10.	Patents and Trademarks	10
11.	Warranty	10

1. Safety 🛆 🕄

For safe installation and use carefully read, understand and keep these Operating Instructions provided. Observe applicable laws, directives and standards.


o:

Not following the information in these Operating Instructions provided with this appliance can result in serious material damage and serious risk to health or life of persons. Only install and operate this appliance and its control panel if they are all in perfect condition. If damaged, contact Whale[®] Support immediately.

It is the sole responsibility of the vehicle owner to ensure that the appliance is in a safe operating condition and is operated correctly.

- Before commencing work, ensure that the vehicle is isolated from any power source.
- Improper installation or repair of Whale[®] heating systems can cause fire or the leakage of deadly carbon monoxide leading to serious injury or death.

Before installation, ensure the appliance is in good condition. If damaged, <u>do not</u> install and contact Whale[®] Support on +44 (0)345 9090 911.



If the electrical supply cord is damaged, it must be replaced by the manufacturer, its service agents or similarly qualified persons in order to avoid a hazard (BS EN 60335-1).

2. Warnings 🖄

In the unlikely event of leaks in the gas system, or if there is a smell of gas:

- Extinguish all naked flames
- · Switch off all appliances and do not operate any electrical switches
- Turn off all gas appliances
- · Open windows and doors for ventilation
- Do not smoke
- Shut off gas connection
- Leave the vehicle

Immediately ensure that the system is thoroughly checked by a registered gas engineer at a Whale[®] Approved Service Centre or by a member of the Whale[®] Service Engineer Network. For Europe, please see enclosed Webasto-Service information.

The Water Heater must not be operated in the following situations:

- When refuelling the vehicle or refuelling the vehicle towing the caravan or any other appliance.
- When the vehicle in which the Water Heater is installed is in motion.
- When the vehicle in which the Water Heater is installed in is in a confined space (such as a garage).

This appliance can be used by children aged from 8 years and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children must not play with the appliance. Cleaning and user maintenance **<u>must not</u>** be carried out by children without supervision.

Before Operation: Ensure the caravan water system, including the Water Heater is full of water, and that the vehicle is level before operating the Water Heater.

This appliance **<u>must be</u>** fully drained if there is a risk of frost. Only when the Frost Protection setting is turned on and activated, the Water Heater does not have to be drained.

Please note: The Frost Protection setting is only recommended for a period of 3 days or less. If the vehicle will not be in use for longer than 3 days, the water system **<u>must be</u>** fully drained.

Please note: The user <u>must ensure</u> that Frost Protection is turned on, activated and remains in operation for the duration for its period of use. Frost damage will not be covered by warranty.

The water temperature cannot be adjusted. It is automatically set to approximately 70° C (or 55° C if eco mode is available and set) and controlled by the heaters control system to prevent bacteria growth. To avoid scalding, the temperature of the hot water supplied to the taps and showers <u>must</u> <u>be</u> controlled at the tap or shower. <u>Do not</u> use the water as drinking water.

Any alteration to the appliance, including flue and flue cover, use of non-Whale[®] spare parts/accessories and non-observation of the installation and operation instructions shall lead to cancellation of the warranty and exclusion of liability claims and results in it becoming illegal to use the appliance.

3. Specification

Flue Type	Type C ₁₃ & C ₅₃ (fanned)	
Destination Countries	AT, BE, BG, CH, CY, CZ, DE, DK, EE, FI, FR, GB, GR, HU, HR, IS, IT, LT, LU, LV, MT, NL, NO, PL, RO, SE, SI, SK, TR	
Dry Storage Temperature	-20°C to 70°C	
Maximum Water Temperature	Approx 72°C	
Battery Supply	10.5 - 15.9V	
Gas Supply	LPG: Butane/Propane 30mbar - CAT I _{38/P (30)}	
IP Rating	IP45	
Nominal Water Capacity	8 Litre	
Max Water Supply Pressure	190kPa (1.9 Bar)	
Rated Pressure	300kPa (3.0 Bar)	
Pressure Relief Valve Setting	300kPa (3.0 Bar)	
Storage Heater Classification	C13	

		Qn [kW]	M [g/hr]	Fuse size [A]	230 V ~ 50Hz [A]	[kg] (Dry) Kg	[kg] (Full) Kg
DW/ WL8212x	2.85	1.35	100	5	6.5	4.5	12.5
DW/ WL8202x	2.85	1.35	100	5	6.5	4.5	12.5

4. Application

The Whale[®] Expanse[™] Water Heater has been designed for caravan, motorhome and mobile applications, and is suitable for small and medium sized recreational vehicles only. It is only suitable for use in recreational vehicles i.e. caravans and motorhomes, but is not suitable for use in caravan holiday homes e.g. mobile homes and static caravans. The compact and lightweight 8L tank can be fitted under the floor or internally and has a variety of power inputs for rapid heat up times.



This symbol indicates that this appliance is suitable for use in leisure accommodation Vehicles.

This symbol indicates that this appliance is not suitable for use in boats.

5. Whale® Water Heater Operating Instructions

To the User: Read the following instructions carefully.

Observe All Warnings

Never operate the Water Heater without water in it. This appliance <u>must not</u> be connected directly to the mains water supply without a pressure regulator fitted, or any water supply greater than 190 kPa (1.9 bar). Ensure that the caravan water system, including this Water Heater is full of water and that the vehicle is level before operating.

When using operating switches provided by the Installer or Vehicle Manufacturer, the Installer or Vehicle Manufacturer are responsible for providing user instructions and identification of symbols on the Control Panel.

When using the Water Heater in winter, ensure the flue is not blocked by snow or fallen leaves etc.

- **Step One:** Upon initial operation or to refill after the system has been drained, check that the drain valve is closed, (see Fig. 1) then fill the system with clean fresh water.
- **Step Two:** To fill, open one hot tap and switch on the water pump.
- **Step Three:** Leave the tap open to allow air to escape while the Water Heater is filling. When water flows smoothly out of the hot tap, the water heater is filled. To allow the remainder of air to escape from the system, open each hot water tap in turn until water flows smoothly from each tap.

Protection Against Frost

If temperatures are likely to fall below zero degree celsius, you **must ensure** that water is drained from the Water Heater. (Unless Frost Protection is in operation). To drain the Water Heater open the drain valve on the Expanse interface to the open position (see Fig. 2). At the same time the taps **must be** open in the hot position to allow air entering the system to aid with the draining process.

Alternatively, if the system is kept active (12V d.c. supply maintained, electrical mains / gas supply available) frost protection can be ensured by enabling frost protection on the control panel.

Periods of Disuse

If the Water Heater is not going to be used for more than 3 days, disable the Water Heater on the control panel, isolate the gas supply by ensuring the gas shut off valve to the Water Heater is closed and that the gas supply is turned off (if no other gas appliances require a continued supply).

Please note: Frost damage will not be covered by warranty.

WARNING OPERATING INSTRUCTIONS - DRAIN VALVE

The drain valve is located at the top of the Water Heater, beside the cold and hot water inlet. To operate the drain valve, turn the yellow lever clockwise 90 degrees to the open position (see Fig. 2). If the plumbing arrangement in the vehicle causes air locking preventing the water heater from draining, consideration should be given to fitting a vacuum relief valve, Whale[®] Part # AK1228.

Please Note: Water will drip from the discharge pipe of the pressure-relief valve during heating up. The pressure relief valve <u>must be</u> operated regularly (at least twice a year) by turning the yellow lever from the closed to open position, to remove lime deposits and to ensure that it is not blocked.




Figure 1. Drain Valve Operation - Closed Position




Figure 2. Drain Valve Operation - Open Position

6. Whale® iVan Control Panel Operation Instructions




Figure 4. Water Heater Icon





Figure 5. Opening Water Heater Control Screen


Whale® iVan Control Panel - Water Heate	r Control Icons and Descriptions
---	----------------------------------

Icon	Description	lcon	Description
3.3A	0.75kW Electric Off	3.3A	0.75kW Electric On
6.5A	1.50kW Electric Off	6.5A	1.50kW Electric On
	Gas Off		Gas On
OFF	Off Button Active	OFF	Off Button Inactive
*	Frost Protection Mode Off	ALL.	Frost Protection Mode Active
*	Frost Protection Mode Selected	×ו	
Reco	Eco Mode Off	eco	Eco Mode Active
Reco	Eco Mode Selected	eco	

Activate Gas Power



And / Or



Whale® iVan Control Panel - Usable Electric Settings for Water Heater

Usable Electric Settings		
3.3A 0.75kW 230V a.c.		3.3A
6.5A 1.50kW 230V a.c.		6.5A

Setting Timers





Figure 6. Whale® iVan Control Panel - Setting Timers for the Water Heater



Activating Timers

Figure 7. Whale® iVan Control Panel - Activating Water Heater Timers

Step 1 - Water Heater Lockout			
Step 2 - Identify Lockout	Step 3 - Recommended Action		
Example Uter Heater Ignition Fault (1) Check Gas Supply To Clear Fault Press RiGHT button on front face of Van Panel	Fault type #1 - Ignition Fault 1. Check Gas Check Gas 2. Temp <5°C, use Propane rather than Butane		
	 Fault type #2-3 - Overheat Fault Check the heater is completely full of water Run pump with one hot tap open until water smoothly flows Go to step 4 		
*Water Heater fault type (#) *Recomended action To Clear Fault: Press RIGHT button on front face of iVan Panel	Fault type #4 - Low Voltage Fault ≥ 10 / ≤ 15V d.c. < 10 / >15V d.c. Go to step 4		
OK	Fault type #5 - Air Pressure Fault1. Check flues for blockages2. Go to step 4		
Example Water Heater Air Pressure Fault (5) Contact Whale Support +44 (0)345 9080 911 CK	Fault types #6-11 Internal fault 1. Go to step 4 2. Call Whale® support +44 (0)345 9090 911.		
*Water Heater fault type (#) Contact Whale Support +44 (0)345 9090 911	Fault type #15 - Multiple faults 1. Power off 2. Check heater for recurring faults 3. Power on 4. Go to step 4		



If problems persist please contact Whale® Support on +44 (0)345 9090 911.

8. Maintenance / Repairs

To clean and sterilise inside the Water Heater use diluted sterilising fluid and fully rinse through with clean water afterwards. The outside of the appliance should not normally require cleaning. If it does, isolate the electrical supplies and wipe down with a soft, damp cloth only. Do not use abrasive cleaners. Allow to fully dry before reconnecting the electrical supplies. If de-scaling of this appliance is required, this can be done using a domestic liquid de-scaling product and fully rinse through with clean water afterwards. Cleaning and user maintenance must not be carried out by children without supervision.

The Whale[®] Water Heater <u>must be</u> checked periodically by a Whale[®] Approved Service Centre / Technician, or competent person, at least annually. This <u>must be</u> completed according to the practice in the country where it is used and according to the Whale[®] instructions. Whale[®] recommends annual testing of gas sound-ness and combustion by an accredited LPG engineer. The appliance contains ESD sensitive components and therefore <u>must only</u> be opened by a Whale[®] Approved Service Centre / Technician. To contact Whale[®] Support, telephone +44 (0)345 9090 911.




Figure 8. Heater Data Label Example

9. EU Declaration of Conformity

Description of Equipment: Gas and Electric Storage Water Heater

Manufacturer's Declaration

We hereby declare, under our sole responsibility, that the above equipment complies with the provisions of the following EC Directives:

Gas Appliance Regulation (EU) 2016/426 (GAR) on the approximation of the laws of the Member States relating to appliances burning gaseous fuels.

Low Voltage Directive 2014/30/EU on the harmonization of the laws of the Member States relating to electrical equipment designed for use within certain voltage limits.

Electromagnetic Compatibility Directive 2014/108/EC, on the approximation of the laws of the Member States relating to electromagnetic compatibility.

CE mark first affixed: 2018.

Basis on which conformity is declared

The above equipment meets the protection requirements of the EMC Directive and the principal elements of the safety objectives of the Low Voltage Directive.

Please contact Whale® if further details are required.

Richard Bovill Engineering Director

10. Patents and Trademarks

The Whale[®] Expanse Water Heater is protected by the following patent and design registrations: - Patent number: EP 2438364, WO 2010091836, GB2529231, GB2529232 and GB2529233. WHALE[®] and IVAN[®] are registered trademarks and EXPANSE[™] is an unregistered trademark of Munster Simms Engineering Limited, Bangor, Northern Ireland.

11. Warranty

The Whale[®] Water Heater is covered by a 2 year warranty. Please complete the enclosed warranty card and return to Whale[®]. For warranty details, please see the enclosed Warranty Statement.

©Copyright Whale 2019 - All rights reserved. Reproduction in whole or in part without permission is prohibited.

WHALE[®], is a registered trademark of Munster Simms Engineering Limited, Bangor, Northern Ireland trading as Whale. Whale's policy is one of continuous improvement and we reserve the right to change specifications without prior notice. Illustrations are for guidance purposes only. Neither the accuracy nor completeness of the information contained in this or any product literature is guaranteed by the Company and may be subject to change at its sole discretion.



Munster Simms Engineering Ltd 2 Enterprise Road, Bangor, N. Ireland BT19 7TA Tel: +44 (0)345 9090 911 info@whalepumps.com

whalepumps.com

